

MOOD - Design by Wendelbo



TECHNICAL SPECIFICATIONS

STRUCTURE INTERIOR

Frame made of solid wood and mdf with nozag spring system.

STRUCTURE PADDING

High resilient variable density polyurethane foam.

SEAT

High resilient polyurethane seat cushion with a wrap of down/feather & ball fibres in a downproof cambric divided into channels.

BACK

Down/feathers & ball fibres in a downproof cambric divided into channels.

COVER

Loose.


LEGS


































Brushed stainless steel.

MAINTENANCE

We recommend shaking and fluffing-up the cushions regularly to maintain the shape. This should be done after removing the cushions from the structure for improved air circulation. For maintenance of fabric and leather, please contact your retailer.

MOOD - Design by Wendelbo



<p>Module 1 (mm)</p>  <p>950 900</p>	<p>Module 2 (mm)</p>  <p>950 680</p>	<p>Module 3 (mm)</p>  <p>950 770</p>	<p>Module 4 (mm)</p>  <p>950 770</p>
<p>Module 5 (mm)</p>  <p>950 1650</p>	<p>Module 6 (mm)</p>  <p>950 1430</p>	<p>Module 7 (mm)</p>  <p>950 1540</p>	<p>Module 8 (mm)</p>  <p>950 1540</p>
<p>Module 9 (mm)</p>  <p>950 1800</p>	<p>Module 10 (mm)</p>  <p>950 1580</p>	<p>Module 11 (mm)</p>  <p>950 1690</p>	<p>Module 12 (mm)</p>  <p>950 1690</p>
<p>Module 13 (mm)</p>  <p>950 1950</p>	<p>Module 14 (mm)</p>  <p>950 1730</p>	<p>Module 15 (mm)</p>  <p>950 1840</p>	<p>Module 16 (mm)</p>  <p>950 1840</p>
<p>Module 17 (mm)</p>  <p>950 2100</p>	<p>Module 18 (mm)</p>  <p>950 1880</p>	<p>Module 19 (mm)</p>  <p>950 1990</p>	<p>Module 20 (mm)</p>  <p>950 1990</p>
<p>Module 21 (mm)</p>  <p>950 2250</p>	<p>Module 22 (mm)</p>  <p>950 2030</p>	<p>Module 23 (mm)</p>  <p>950 2140</p>	<p>Module 24 (mm)</p>  <p>950 2140</p>
<p>Module 25 (mm)</p>  <p>950 2400</p>	<p>Module 26 (mm)</p>  <p>950 2180</p>	<p>Module 27 (mm)</p>  <p>950 2290</p>	<p>Module 28 (mm)</p>  <p>950 2290</p>
<p>Module 29 (mm)</p>  <p>1550 900</p>	<p>Module 30 (mm)</p>  <p>1550 900</p>	<p>Module 31 (mm)</p>  <p>950 950</p>	<p>Module 32 (mm)</p>  <p>800 1000</p>
			<p>Module 33 (mm)</p>  <p>600 1000</p>